



UBECUBE

4429 E 139th St
Grandview, MO 64030
816.775.2044

CRATEVINYL DJ - INSTRUCTION MANUAL



KIT INCLUDES:

- UC01 Crate [x1]
- Window MOD Panel [x2]
- CrateDivider™ Kit [x1]
- Handle Kit [x1]



WARNINGS & GENERAL SAFETY


- ⊘ Do Not use the Crates to stand on
- ⊘ Do Not sit on the Crate
- ⊘ Do Not load more than 50 pounds

General Safety Information

- Read the instruction manual before use
- Keep the instruction manual for reference
- Recommended age of use is 12 years and older
- Pinch point hazard - Use caution when collapsing or erecting

UC01 CRATE ASSEMBLY


Unpack & Level



1

Remove packaging from around the crate. Place the crate on a flat, level surface with the **lid side facing up**.


Pull Up



2

Grip the top rim of the crate on opposite sides and pull it upwards. **Pull out any accessories** from inside the crate.


Swing Down



3

Swing down the two full side panels: Reach inside and pull down each full side panel until they are both positioned vertically.


Lock Sides



4

Lock the full side panels in place: Push down on the locks on each full side panel until they snap securely.

Inspect




5

Ensure tabs are aligned: Make sure the tabs on the full side panels snap into the corresponding slots on the folding panels.

SIDE PANEL ASSEMBLY


Unlock Panel



1

Place the crate on a flat, level surface. Turn each of the **four panel locks** a **quarter turn** to unlock them.


Pop Out Panel



2

Release the panel by pushing inward on each of its four corners from the outside of the crate. This will "pop" the panel out.

Re-Secure Panel




3

From the **inside of the crate**, push the panel back into place until it snaps securely on all sides. Turn all four panel locks back to their locked position.

HANDLE KIT ASSEMBLY

Unlock Panel



1

Rotate **all four of the Pin Locks 90 degrees clockwise** to unlock the grid panel.


Remove Panel



2

Remove the panel by **pushing inward on each of its four corners** from the outside of the crate.

Remove Pin Locks



3

Rotate two Pin Locks 90 degrees, then **press the pin button with a flathead screwdriver while pulling the pin out** of the casing.


Re-Secure Panel



4

Insert the Grid Panel back into the crate and **rotate the lower two Pin Locks** to lock the Grid Panel in place.


Assemble Handle



5

Press the rubber handle opening over the metal anchor cylinder until it wraps fully around the anchor.


Handle To Panel



6

Insert the back side of the Rubber Handle assembly **into the empty Pin Lock cavity**.


Tighten Bolt



7

From **inside the crate**, insert the bolt and tighten it into the Handle assembly with a flathead screwdriver.

Repeat 6 & 7




8

Repeat steps 6 & 7 for the **other side** of the handle until both sides are secure.

CRATERAIL INSTALL


Place On Side



1

Open the lid and rotate the crate 90 degrees, positioning one full side panel flat on a hard surface.


Insert CrateRail



2

Insert the CrateRail into the side panel, ensuring both bumps on one side of the CrateRail align and fit through the openings on the panel.


Secure CrateRail



3

Use a hammer to tap each end of the CrateRail until it snaps through the panel and locks firmly into place.


Repeat



4

Rotate the crate 180 degrees and repeat steps 2 and 3 on the other full side panel making sure both CrateRails are firmly in place.

Slide In Divider



5

Once both CrateRails are secure, slide the divider into place by guiding it through the CrateRails.