
CRATESHELF™ KIT INSTALL


Place On Side



1

Open the lid and rotate the crate 90 degrees, positioning one full side panel flat on a hard surface.

Insert CrateFin



2

Insert the CrateFin into the side panel, ensuring both bumps on one side of the CrateFin align and fit through the openings on the panel.

Secure CrateFin



3

Use a hammer to tap each end of the CrateFin until it snaps through the panel and locks firmly into place.


Repeat



4

Rotate the crate 180 degrees and repeat steps 2 & 3 on the other full side panel making sure both CrateFins are firmly in place.

Slide In Shelf



5

Once both CrateFins are secure, **slide the shelf panel** into place by guiding it over the CrateFins.

SECURING THE CRATES


Stack Crates



1

Assemble and **stack the crates against the wall** to the desired tower height.


Snap-Fit Connect



2

Press the Snap-Fit Connectors **through the aligned grid openings** until they snap in place to secure the tower.


Insert & Mark



1

Snap the Screw Clip into an **inside grid opening and mark the wall** through the screw hole.

Screw Into Wall



2

Remove the crate, **install anchors**, then reposition the crate and **screw through the clip to secure.**

1/4 TURN ATTACHMENTS

Insert Attachment



1

Insert the CrateHook into the grid openings **at a 45-degree angle.**

1/4 Turn



2

Rotate the CrateHook 45 degrees until it locks securely onto the crate panel.

Calculating Wooden Top Dimensions

Depth: 13.75" (crate dimension) + overlap

Length: (13.75" x3)

Recommended Dimensions

Depth: 14"

Length: 41.75"

Thickness: 1" - 1.5"

Visit us @ ubecube.com to learn more!!

UBECUBE

4429 E 139th St
Grandview, MO 64030
816.775.2044

KICKSTAND GRID - INSTRUCTION MANUAL





KIT INCLUDES:

- UC02 Lidless Crate (x9)
- CrateShelf™ Kit (x9)
- CrateHook™ (x2)
- Short Poles (x6)
- Snap-Fit Connector (x16)
- Screw Clip Set (x3)

⚠ WARNINGS & GENERAL SAFETY

- Do Not use the Crates to stand on
- Do Not sit on the Crate
- Do Not load more than 50 pounds

General Safety Information

- Read the instruction manual before use
- Keep the instruction manual for reference
- Pinch point hazard - Use caution when folding, unfolding, stacking, or connecting crates.
- Always secure crate towers taller than three crates to the wall using Screw Clips.

UC02 CRATE ASSEMBLY


Unpack & Level



1

Remove packaging from around the crate. Place the crate on a flat, level surface with the **rim side facing up.**


Pull Up



2

Grip the top rim of the crate on opposite sides and pull it upwards. **Pull out any accessories** from inside the crate.


Swing Down



3

Swing down the two full side panels: Reach inside and pull down each full side panel until they are both positioned vertically.


Lock Sides



4

Lock the full side panels in place: Push down on the locks on each full side panel until they snap securely.

Inspect



5

Ensure tabs are aligned: Make sure the tabs on the full side panels snap into the corresponding slots on the folding panels.